

How to Customize Interior Light-Dimming Time –DA Models

Most Honda models come standard with Display Audio, which can be used to customize several features, including how long the interior lighting stays on after you close the doors.



Follow these steps:

1. With the vehicle in **Park**, turn the ignition to **Accessory** or **On**
2. Touch **Settings**
3. Touch **Vehicle**
4. Touch **Lighting Setup**
5. Select **Interior Light Dimming Time**
6. Select from: **15sec, 30sec, 60sec**
7. Confirm your choice